


## SingScreen – Safety & Care



### **Safety Instructions**

Never lift the stand by the screen – this may cause it to fracture.

Always lift the stand by the lower section so as not to place pressure on any of the joints or bolts holding it together.

Always follow safe lifting practices and never bend only from the back, this can cause injury.

Always keep the safety corner covers on the screen, this reduces any chance of injury and makes the screen perceptible.

### **Care Instructions**

Use a soft damp cloth to clean the product and if necessary, with a household detergent, or recommended Perspex Cleaners.

Never use abrasive products on the Perspex or Stand.

We recommend you cover the Perspex when transporting the product to avoid damaging its surface.

**\* These suggestions are not exhaustive and SingScreen takes no liability from misuse of the product. Always follow your employers or venues health and safety guidelines when using this product. \***